Quick Installation Guide

OCTAGON
### SF3038 E2 HD

Triple Tuner PVR

SAFETY INSTRUCTIONS

o This product operates only in the range of AC 100V~250V and 50Hz/60Hz. Please check first your power supply to see if it fits this range.

o Please be noted that you need to disconnect from the mains before you start any maintenance or installation procedures.

o Make sure that the power cord is placed in a position where it is easy to unplug it from the mains in an emergency.

o Do not overload a wall outlet, extension cord or adapter as this may cause electrical fire or shock.

o This product is not water-proof and should not be exposed to dripping, splashing, or any type of liquid.

o No objects filled with liquid such as vase shall be placed on the product.

o Please do not clean the product with wet cloth, which may cause a short circuit.

o No wet objects should be placed near the product.

o Disconnect the power of the product before you connect the satellite cable to the product. Otherwise, it may cause damage to the LNB.

o The LNB must be earthed to the system earth for the satellite dish.

o Unplug the product and disconnect the antenna cable during a thunderstorm or lightening, especially when left unattended and unused for a long period of time. This will prevent possible damages from power surges or lightening

o Place the product indoor.

o Do not expose the product to rain, sun or lightening.

o Do not place the product near any heat appliances as a radiator.

o Ensure that there is more than 10 cm distance from any electrical devices & wall.

2

# INCLUDED CONTENTS

- SF3038 E2 HD

| HDMI Cable | Loopthrough Cable | A/C Adaptor |
| Quick Installation Guide | Batteries (AAA) | RCU |

3

CONNECTION GUIDE

Satellite

Terrestrial/Cable

Optical S/PDIF

HDMI

RCA/Component

TV

Digital Audio Equipment

• Hybrid tuner supports both Terrestrial & Cable reception.
• Tuner combination may vary according to your choice (Tuner modules can be purchased separately).

4

SF3038

No.	Name	Description
1	Power	Turn the product on or standby.
2	Mute	Mute/unmute audio.
3	F1	MediaPortal shortcut
4	F2	Media Center (bmediacenter) shortcut
5	F3	User defined key
6	Help	Displays major important operation methods of STB. This provides users with a quick guide using of STB.
7	Numeric Keys	Enters a channel number or numbers according to the menu options.
8	<	History Zap
9	>	History Zap
10	Volume +/-	Adjusts audio volume.
11	Context	Chooses an extension
12	Guide	Displays the Electronic Program Guide (EPG) information if provided.
13	Channel (Page) up/down	Navigates through the scanned channel list. or Move the channel/Program list in pages.
14	Menu	Displays the main menu.
15	Exit	Exits the current menu option into the live mode, or switchesone step back of the menu.
16	Info	Displays the service information box. It is also used to display more information about a program.
17	Recall	History Zap

No.	Name	Description
18	OK	Confirms the selected menu option.
19	Navigation Keys	Navigates Up/Down and Left/Right on the menu options. Up/down keys are used to call up the channel list.
20	Color Keys	Each key is assigned a specific function that may be different in each menu.
21	Fast Rewind	Faster rewind than the normal speed.
22	Play	Play
23	Pause	Pause
24	Fast Forward	Faster forward than the normal speed.
25	Audio	Displays the audio track option to choose (e.g. AC3, Stereo).
26	Stop	Stops playing and goes to the live mode.
27	Recording	Starts recording media.
28	Playlist	Displays the list of recordings stored on the external HDD if any.
29	Teletext	Displays the teletext information of the current channel, if the channel provides teletext data.
30	TV	Displays the TV channel list
31	Radio	Displays the Radio channel list.
32	FAV	Displays Favorite channel list.

Power Supply

Power Type	External Adaptor
Power Consumption	12Vd.c./2500mA
Input Voltage	100-240V a.c., 50/60Hz
Protection	Separate Internal Fuse & Lightning protection

Physical Specification

Size (W x H x D)	260 x 45 x134 (mm)

'WEEE' Instructions

This product should not be disposed with other household wastes at the end of its working life. Please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources. This will prevent possible harm to the environment or human health from uncontrolled waste disposal.

You can get more information about how to use SF3038 at http://book.mynonpublic.com/.